

CLEVERTOUCH®



UX Pro Edge

Android 15 Settings

Contents

Network & Internet 3

Advanced 4

Administrator..... 5

Connected Devices..... 6

Apps..... 7

Notifications..... 8

Storage..... 9

Sound..... 10

Display 11

Wallpaper 12

Accessibility 13

Security & Privacy 14

Location 15

Passwords, Passkeys & Accounts 16

Digital Wellbeing & Parental Controls..... 17


Google..... 18

System 19

About 20

Network & Internet


Manage your device’s network connections.



Item	Description
Ethernet	Configure and manage Ethernet connection and preferences.
Internet	Configure and manage Wi-Fi connection and preferences.
Airplane Mode	When enabled, all wireless communication will be disabled.
Hotspot & Tethering	Configure your Hotspot and share your connection with other devices.
Data Saver	When enabled, most apps and services can use background data over an internet connection. Active apps are not affected.
VPN	Configure and manage Virtual Private Network (VPN) connections.
Share Network	When enabled, allows the device to share network with USB connected devices.
Private DNS	Use Automatic Private DNS or configure one manually to enhance security and privacy.

Advanced

Access additional system settings.




Item	Description
Date format	Configure how dates are displayed on the device.
Country & region	Select your country or region.
Input & Output	Configure input devices and output options.
Show Android status bar	Enable or disable the Android status bar.
SystemDock Channel Settings	Configure the channel settings for the floating pen tool.
Home Application	Select a default home application.
Power Button	Configure the functionality of the power button.
Startup & shutdown	Configure startup & shutdown, energy and scheduler settings.
Display	Configure display settings.
Multi-Windows mode	Enable or disable multi-windows mode.
PIR Settings	Configure PIR detection settings.

Gesture	Enable and customise gesture controls.
Block Saving	Prevent files or content from being saved to the device.
Whiteboard	Select your default whiteboard.

Administrator


Configure device administrator options and permissions.



Item	Description
Enable Administrator	Enable or disable administrator privileges for device management.
Change administrator password	Update the password for the administrator account.
Wake On LAN	Enable or disable wake on LAN.
HDMI CEC	Enable or disable to control HDMI devices through Consumer Electronics Control.
USB Clone	Clone Settings/OSD/Debug menu to a USB drive.
Security Lock	Configure security features to restrict device access.

Connected Devices


Configure and control Bluetooth connections, saved devices, and preferences for Bluetooth, Casting, and Print Services.



Item	Description
USB	Configure USB connections and settings.
Pair new device	Connect and pair with a new Bluetooth device.
See all	View all saved devices.
Connection preferences	Configure preferences for device, NFC, casting and quick share connections.

Apps


View, configure, and control installed applications.



Item	Description
Recently opened apps	View and manage apps you've recently used.
Default apps	Set default applications for various actions.
Screen time	Monitor and control device usage.
Cloud media app	Configure what apps are used for accessing cloud based media.
Unused apps	Identify and manage apps you haven't used recently.
Special app access	Manage special permissions for specific apps.

Notifications

Customize how notifications are delivered and displayed.




Item	Description
App notifications	Manage notifications for individual apps.
Notification history	View recently received notifications.
Conversations	Prioritise and manage messaging notifications.
Bubbles	Enable or disable chat bubbles for conversations.
Notification read, reply & control	Control how notifications can be read and responded to.
Notifications on lock screen	Choose which notifications appear when the device is locked.
Sensitive notifications	Enable or disable visibility of sensitive notifications when the device is locked.
Do Not Disturb	Configure Do Not Disturb settings.
Flash notifications	Use screen flashes for alerts.
Wireless emergency alerts	Configure emergency alerts and broadcasts.
Hide silent notifications in status bar	Enable or disable the visibility of silent notifications from the status bar.

Allow notification snoozing	Enable or disable notification snoozing.
Notification dot on app icon	Enable or disable dots on app icons to indicate new notifications.
Enhanced notifications	Enable or disable advanced notification features and controls.

Storage

Monitor and manage device storage space.




Item	Description
Storage Manager	When enabled, the storage manager will monitor and optimise device storage.
Images	View and manage stored images.
Videos	View and manage stored video files.
Audio	View and manage music, recordings and other audio files.
Apps	View and manage installed applications.
Games	View and manage installed games and related data.
Documents	View and manage text files, PDFs and other documents.

Other	View and manage other files not covered by other categories.
Trash	View and manage deleted files.
System	View and manage system files and storage used by the operating system.

Sound


Adjust audio settings and output preferences.



Item	Description
Media volume	Adjust the volume for music, videos and other media.
Audio will play on	Select the output for audio playback.
Do Not Disturb	Configure Do Not Disturb settings.
Live Caption	Enable real-time captions for audio and video.
Media	Manage media playback settings and options.
Default notification sound	Choose the sound for incoming notifications.
Default alarm sound	Set the alarm tone for alarms and timers.
Tap & click sounds	Enable or disable sounds for touch and click actions.

Display


Configure display settings like lock screen and text size.



Item	Description
Lock screen	Configure settings for the device's lock screen appearance and behaviour.
Screen timeout	Set the duration before the screen turns off due to inactivity.
Dark theme	Enable a dark colour scheme to reduce eye strain and lower power consumption.
Display size and text	Adjust the size of on-screen elements and text for better readability.
Screen saver	Set up a screen saver to display when the device is idle.

Wallpaper


Personalize your device’s background and lock screen appearance.



Item	Description
Lock screen	Allows for customisation of lock screen.
Home screen	Allows for customisation of home screen.
Clock colour & size	Customise the clock’s colour and size on the lock screen.
More Wallpapers	Browse and select additional wallpaper options.
More Colours	Access a wider range of colours for customisation.
Show notifications on the lock screen	Choose whether to display notifications on the lock screen.
More lock screen options	Access additional settings to personalise the lock screen experience.
Themed icons	Apply a consistent style to app icons for a unified look.

Accessibility

Enable features that improve device usability for all users.




Item	Description
Accessibility Float Window	Enable or disable the CleverShare floating window.
OCR Input	Use Optical Character Recognition to input text from images.
Select to Speak	Tap items on screen to have them read aloud.
Switch Access	Control the device using external switches instead of touch.
TalkBack	Enable spoken feedback for screen navigation.
Display size and text	Adjust on-screen element and text size for easier viewing.
Colour and Motion	Customise colour settings and reduce motion effects.
Magnification	Zoom in on parts of the screen for better visibility.
Accessibility Menu	Access a larger on-screen menu for common actions.
Timing Controls	Adjust time limits for interactions and responses.
System Controls	Manage the systems navigation mode.

Live Caption	Automatically generate captions for audio and video.
Caption Preferences	Customise behaviour and appearance of captions.
Audio description	Enable narrated descriptions of visual content.
Flash notifications	Use screen flashes for alerts.
Audio adjustment	Fine-tune audio settings for better clarity.
Accessibility shortcuts	Set up quick shortcuts to toggle accessibility features.
Text-to-speech output	Configure voice settings for spoken text.

Security & Privacy

Protect your device and data with security settings.




Item	Description
Check for updates	Search for and install system and security updates.
App security	Configure security settings for user accounts.
Device unlock	Set or change the method to unlock your device.
Account security	Manage security settings for user accounts.
Device finders	Enable tools to locate your device if lost or stolen.

System & updates	Access system information, backup options and update options.
Privacy controls	Manage app permissions and privacy settings.
Privacy dashboard	View and control how apps access your data.
Private space	Create a secure area on your device for sensitive data.
More security & privacy	Access additional security and privacy options.

Location


Manage location services and permissions.



Item	Description
Use location	Enable or disable location services on the device.
Recent access	View apps that have recently accessed your location.
App location permissions	Manage which apps can access your location.
Location services	Configure settings related to GPS and other location settings.

Passwords, Passkeys & Accounts


Manage saved credentials and user accounts.



Item	Description
Preferred service	Select the default service to use for account related features.
Accounts for Owner	Manage user accounts linked to the device user.
Automatically sync app data	Enable or disable automatic synchronisation of app data.

Digital Wellbeing & Parental Controls


Monitor device usage and set restrictions.



Item	Description
Your Digital Wellbeing Tools	An overview of device usage, unlocks and notifications.
View app activity details	See detailed usage stats for individual apps.
App timers	Set limits on daily app usage.
Bedtime mode	Adjust display settings to prepare for sleep.
Focus	Minimise interruptions by limiting notifications and app access.
Screen time reminders	Receive alerts about your screen usage.
Manage notifications	Control which applications can deliver notifications.
Do Not Disturb	Configure Do Not Disturb settings.
Heads Up	Get alerts to take breaks and reduce screen time.
Show icon in the app list	Display or hide Digital Wellbeing app in the device's app list.
Parental controls	Set restrictions and monitor device usage.

Google


Access and configure Google services and settings.



Item	Description
Recommended	Suggested services based on your usage and preferences.
All services	View and manage all available Google and device services.

System


Manage system settings and perform updates.



Item	Description
Languages	Set and manage device languages.
Keyboard	Configure keyboard settings and text tools.
Gestures	Enable and customise gesture controls.
Date & time	Set device date, time and time zone options.
Backup	Manage data backup settings.
System Update	Check for and install Clevertouch software updates.
Users	Add or manage multiple user profiles on the device.
Reset options	Restore device settings or perform a factory reset.

About

View detailed information about your device and software.



Item	Description
Device name	View or change the name of your device.
Legal information	View the relevant legal information.
Model	View the model number of the IMPACT Lux.
Android version	View the current Android operation system version.
IP address	View the devices IP address.
Wi-Fi MAC address	View the Wi-Fi MAC address.
Device Wi-Fi MAC address	View the Device Wi-Fi MAC address.
Bluetooth address	View the Bluetooth address.
Uptime	View how long the device has been in operation.
Build number	View the devices build number.